

COMMAND RADIO  
RECEIVER-TRANSMITTER  
RT-1145( )/ARC-164(V) OR  
RT-1504/ARC-164(V) MOUNT-  
ING ADAPTER MT-4646

COMMAND  
RADIO  
ANTENNA  
AT-256A/ARC

TO IFF

COMMAND  
RADIO RELAY

W1354

TO AIRCRAFT POWER

TO INTERPHONE

COMMAND RADIO  
FREQUENCY INDICATOR  
ID-1961/ARC

2 4 6 8 11  
UHF

W1323

COMMAND RADIO  
CONTROL PANEL  
C-9680( )/ARC-  
164(V) OR C-11719/  
ARC-164(V)

TYPICAL

W1322

FIGURE 14

AN/ARC-164(V) UHF Command Radio System Cabling Diagram

